

Bit number		31 30 29 28 27 26 25 24 23 22 21 20 19 18 17 16 15 14 13 12 11 10 9 8 7 6 5 4 3 2 1 0		
ID		D C B A		
Reset 0x00000000		0 0		
ID	R/W Field	Value ID	Value	Description
C	RW TXPTRUPD			Enable or disable interrupt for event TXPTRUPD
		Disabled	0	Disable
		Enabled	1	Enable
D	RW FRAMESTART			Enable or disable interrupt for event FRAMESTART
		Disabled	0	Disable
		Enabled	1	Enable

8.11.10.14 INTENSET

Address offset: 0x304

Enable interrupt

Bit number		31 30 29 28 27 26 25 24 23 22 21 20 19 18 17 16 15 14 13 12 11 10 9 8 7 6 5 4 3 2 1 0		
ID		D C B A		
Reset 0x00000000		0 0		
ID	R/W Field	Value ID	Value	Description
A	RW RXPTRUPD			Write '1' to enable interrupt for event RXPTRUPD
	W1S			
		Set	1	Enable
		Disabled	0	Read: Disabled
		Enabled	1	Read: Enabled
B	RW STOPPED			Write '1' to enable interrupt for event STOPPED
	W1S			
		Set	1	Enable
		Disabled	0	Read: Disabled
		Enabled	1	Read: Enabled
C	RW TXPTRUPD			Write '1' to enable interrupt for event TXPTRUPD
	W1S			
		Set	1	Enable
		Disabled	0	Read: Disabled
		Enabled	1	Read: Enabled
D	RW FRAMESTART			Write '1' to enable interrupt for event FRAMESTART
	W1S			
		Set	1	Enable
		Disabled	0	Read: Disabled
		Enabled	1	Read: Enabled

8.11.10.15 INTENCLR

Address offset: 0x308

Disable interrupt

Bit number		31 30 29 28 27 26 25 24 23 22 21 20 19 18 17 16 15 14 13 12 11 10 9 8 7 6 5 4 3 2 1 0		
ID		D C B A		
Reset 0x00000000		0 0		
ID	R/W Field	Value ID	Value	Description
A	RW RXPTRUPD			Write '1' to disable interrupt for event RXPTRUPD
	W1C			
		Clear	1	Disable