

Bit number			31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
ID			O	N	M	L	K	J	I	H	G	F	E	D	C	B	A																	
Reset 0x00000000			0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0				
ID	R/W	Field	Value ID	Value	Description																													
			Enabled	1	Read: Enabled																													
F	RW	RXFRAMESTART			Write '1' to enable interrupt for event RXFRAMESTART																													
		W1S			Set	1	Enable																											
					Disabled	0	Read: Disabled																											
					Enabled	1	Read: Enabled																											
G	RW	RXFRAMEEND			Write '1' to enable interrupt for event RXFRAMEEND																													
		W1S			Set	1	Enable																											
					Disabled	0	Read: Disabled																											
					Enabled	1	Read: Enabled																											
H	RW	ERROR			Write '1' to enable interrupt for event ERROR																													
		W1S			Set	1	Enable																											
					Disabled	0	Read: Disabled																											
					Enabled	1	Read: Enabled																											
I	RW	RXERROR			Write '1' to enable interrupt for event RXERROR																													
		W1S			Set	1	Enable																											
					Disabled	0	Read: Disabled																											
					Enabled	1	Read: Enabled																											
J	RW	ENDRX			Write '1' to enable interrupt for event ENDRX																													
		W1S			Set	1	Enable																											
					Disabled	0	Read: Disabled																											
					Enabled	1	Read: Enabled																											
K	RW	ENDTX			Write '1' to enable interrupt for event ENDTX																													
		W1S			Set	1	Enable																											
					Disabled	0	Read: Disabled																											
					Enabled	1	Read: Enabled																											
L	RW	AUTOCOLRESSTARTED			Write '1' to enable interrupt for event AUTOCOLRESSTARTED																													
		W1S			Set	1	Enable																											
					Disabled	0	Read: Disabled																											
					Enabled	1	Read: Enabled																											
M	RW	COLLISION			Write '1' to enable interrupt for event COLLISION																													
		W1S			Set	1	Enable																											
					Disabled	0	Read: Disabled																											
					Enabled	1	Read: Enabled																											
N	RW	SELECTED			Write '1' to enable interrupt for event SELECTED																													
		W1S			Set	1	Enable																											
					Disabled	0	Read: Disabled																											
O	RW	STARTED			Write '1' to enable interrupt for event STARTED																													
		W1S			Set	1	Enable																											
					Disabled	0	Read: Disabled																											