

Bit number			31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
ID			M	L	K	J	I	H	G	F	E D C B A																							
<b>Reset 0x00000000</b>			0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0				
ID	R/W	Field	Value ID	Value	Description																													
			Disabled	0	Disable shortcut																													
			Enabled	1	Enable shortcut																													
C	RW	LASTTX_STOP			Shortcut between event <a href="#">LASTTX</a> and task <a href="#">STOP</a>																													
			Disabled	0	Disable shortcut																													
			Enabled	1	Enable shortcut																													
D	RW	LASTRX_DMA_TX_START			Shortcut between event <a href="#">LASTRX</a> and task <a href="#">DMA.TX.START</a>																													
			Disabled	0	Disable shortcut																													
			Enabled	1	Enable shortcut																													
E	RW	LASTRX_STOP			Shortcut between event <a href="#">LASTRX</a> and task <a href="#">STOP</a>																													
			Disabled	0	Disable shortcut																													
			Enabled	1	Enable shortcut																													
F-I	RW	DMA_RX_MATCH[i]_DMA_RX_ENABLEMA +1%4] (i=0..3)			Shortcut between event <a href="#">DMA.RX.MATCH[n]</a> and task <a href="#">DMA.RX.ENABLEMATCH[(i+1)%4]</a>																													
			Disabled	0	Allows daisy-chaining match events.																													
			Enabled	1	Disable shortcut																													
J-M	RW	DMA_RX_MATCH[i]_DMA_RX_DISABLEMATCH[i] (i=0..3)			Shortcut between event <a href="#">DMA.RX.MATCH[n]</a> and task <a href="#">DMA.RX.DISABLEMATCH[n]</a>																													
			Disabled	0	Disable shortcut																													
			Enabled	1	Enable shortcut																													

## 8.23.10.22 INTEN

Address offset: 0x300

Enable or disable interrupt

Bit number			31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
ID			O	N	M	L	K	J	I	H	G	F	E D C B A																					
<b>Reset 0x00000000</b>			0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0				
ID	R/W	Field	Value ID	Value	Description																													
A	RW	STOPPED			Enable or disable interrupt for event <a href="#">STOPPED</a>																													
			Disabled	0	Disable																													
			Enabled	1	Enable																													
B	RW	ERROR			Enable or disable interrupt for event <a href="#">ERROR</a>																													
			Disabled	0	Disable																													
			Enabled	1	Enable																													
C	RW	SUSPENDED			Enable or disable interrupt for event <a href="#">SUSPENDED</a>																													
			Disabled	0	Disable																													
			Enabled	1	Enable																													
D	RW	LASTRX			Enable or disable interrupt for event <a href="#">LASTRX</a>																													
			Disabled	0	Disable																													
			Enabled	1	Enable																													
E	RW	LASTTX			Enable or disable interrupt for event <a href="#">LASTTX</a>																													
			Disabled	0	Disable																													
			Enabled	1	Enable																													
F	RW	DMARXEND			Enable or disable interrupt for event <a href="#">DMARXEND</a>																													
			Disabled	0	Disable																													
			Enabled	1	Enable																													