

Bit number		31 30 29 28 27 26 25 24 23 22 21 20 19 18 17 16 15 14 13 12 11 10 9 8 7 6 5 4 3 2 1 0			
ID	B	A A A A A A A A			
<b>Reset 0x00000000</b>		<b>0 0</b>			
ID	R/W	Field	Value ID	Value	Description
A	RW	CHIDX	[0..255]	DPPI channel that event <b>DONE</b> will publish to	
B	RW	EN			
		Disabled	0	Disable publishing	
		Enabled	1	Enable publishing	

### 8.18.11.18 PUBLISH\_DONE

Address offset: 0x188

Publish configuration for event **DONE**

Bit number		31 30 29 28 27 26 25 24 23 22 21 20 19 18 17 16 15 14 13 12 11 10 9 8 7 6 5 4 3 2 1 0			
ID	B	A A A A A A A A			
<b>Reset 0x00000000</b>		<b>0 0</b>			
ID	R/W	Field	Value ID	Value	Description
A	RW	CHIDX	[0..255]	DPPI channel that event <b>DONE</b> will publish to	
B	RW	EN			
		Disabled	0	Disable publishing	
		Enabled	1	Enable publishing	

### 8.18.11.19 PUBLISH\_RESULTDONE

Address offset: 0x18C

Publish configuration for event **RESULTDONE**

Bit number		31 30 29 28 27 26 25 24 23 22 21 20 19 18 17 16 15 14 13 12 11 10 9 8 7 6 5 4 3 2 1 0			
ID	B	A A A A A A A A			
<b>Reset 0x00000000</b>		<b>0 0</b>			
ID	R/W	Field	Value ID	Value	Description
A	RW	CHIDX	[0..255]	DPPI channel that event <b>RESULTDONE</b> will publish to	
B	RW	EN			
		Disabled	0	Disable publishing	
		Enabled	1	Enable publishing	

### 8.18.11.20 PUBLISH\_CALIBRATEDONE

Address offset: 0x190

Publish configuration for event **CALIBRATEDONE**

Bit number		31 30 29 28 27 26 25 24 23 22 21 20 19 18 17 16 15 14 13 12 11 10 9 8 7 6 5 4 3 2 1 0			
ID	B	A A A A A A A A			
<b>Reset 0x00000000</b>		<b>0 0</b>			
ID	R/W	Field	Value ID	Value	Description
A	RW	CHIDX	[0..255]	DPPI channel that event <b>CALIBRATEDONE</b> will publish to	
B	RW	EN			
		Disabled	0	Disable publishing	
		Enabled	1	Enable publishing	